



Paradise In Your Backyard®

Deck Clamp Warnings & Instructions

Securely mounts torches to your deck rail, baluster or stable components up to 1 1/2" thick. Fits poles up to 1" in diameter.

INSTRUCTIONS:

Place bracket around deck rail or baluster, a minimum of 1 1/2", and securely tighten large thumbscrew. If fastening to a horizontal rail, orient bracket so large thumbscrew is facing down. Insert pole through both V shaped holes in bracket to desired height and securely tighten small thumbscrew. Ensure that the pole is securely fastened in the mounting bracket before each use.

CALIFORNIA PROP. 65 WARNING:

This product may contain chemicals known to the State of California to cause cancer, birth defects or reproductive harm.

WARNING: Keep a minimum of 1/3 of total pole length protruding from the bottom of the clamp to avoid the torch from tipping when attached to the deck clamp. The deck clamp must engage deck rail a minimum of 1 1/2" for a secure fit. Example: Pole length = 30 inches, protrusion length = 10 inches

©2015 Lamplight Farms Inc. W140 N4900 Lilly Rd., Menomonee Falls, WI 53051
TIKI® & Paradise In Your Backyard® are trademarks of Lamplight Farms Inc. / TIKI® y Paradise In Your Backyard® son marcas de Lamplight Farms Inc.
www.tikibrand.com
Made in China/Hecho en China
Customer Service/Servicio al cliente: 1-888-473-1088

Monta de forma segura antorchas a su baranda, balaustre o componentes estables de hasta 44,45 mm de grosor. Se ajusta a postes de hasta 2,54 cm de diámetro.

INSTRUCCIONES:

Coloque la abrazadera alrededor de la baranda o balaustre, a un mínimo de 3,81 cm, y asegure firmemente el tornillo de mariposa grande. Si la está fijando a un travesaño horizontal, oriente la abrazadera de modo que el tornillo de mariposa grande apunte hacia abajo. Inserte el poste a través de ambos orificios con forma de V en la abrazadera hasta la altura deseada y asegure bien el tornillo de mariposa pequeño. Asegúrese de que el poste esté bien sujeto a la abrazadera de montaje antes de cada uso.

ADVERTENCIA:

Conserve un mínimo de 1/3 del largo total del poste sobresaliendo de la parte inferior de la abrazadera para evitar que la antorcha se incline cuando se fije a la abrazadera de la terraza. La abrazadera de la terraza deberá enganchar en la baranda de la terraza un mínimo de 1 1/2" (3,8 cm) para quede segura. Ejemplo: Largo del poste = 30 pulgadas (76,2 cm), largo que debe sobresalir = 10 pulgadas (25,4 cm)