



Paradise In Your Backyard®

Metal Torch Warnings & Instructions

DANGER: TORCH FUEL IS HARMFUL OR FATAL IF SWALLOWED. CONTAINS PETROLEUM HYDROCARBONS. READ WARNINGS ON TORCH FUEL CONTAINER CAREFULLY.

WARNING: FOR OUTDOOR USE ONLY! KEEP OUT OF REACH OF CHILDREN AND PETS. NEVER LEAVE A BURNING TORCH UNATTENDED. FAILURE TO FOLLOW WARNINGS AND INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE.

WARNING: USE ONLY TIKI® BRAND TORCH FUEL. DO NOT USE GASOLINE OR OTHER FLAMMABLE FUELS.

CAUTION: Use only in well-ventilated area. Do not use in windy conditions. Use only TIKI® Brand wicks. Do not tip torch as fuel can spill and cause fire or serious injury. Store fuel in original fuel bottle with cap secured, and dispose of any unwanted fuel in accordance to local laws and regulations.

INSTRUCTIONS FOR USE:

- 1. INSTALLING:** Insert torch pole into ground minimum of 6" until secured. Do not place torch under covered shelter or umbrellas, near pedestrian traffic or combustibles such as wood structures, fuel, clothing or dry vegetation. Retain these instructions for reference.
- 2. FILLING:** Unscrew metal flame guard from canister and fill with TIKI® Brand Torch Fuel. DO NOT OVER FILL. Reattach metal flame guard to canister. DO NOT OVER TIGHTEN. Wipe away any spilled fuel before lighting. Place canister in torch.
- 3. LIGHTING:** Allow wick to become saturated with fuel. Exposed wick should be no higher than 1/2".
CAUTION: Keep clothing, hair and face away from flame when lighting.
- 4. EXTINGUISHING:** Using the snuffer cap that is attached to the torch, carefully place completely over wick until flame is extinguished. Place snuffer cap over wick to protect from elements. Allow to cool for 30 minutes before handling and refilling.

©2015 Lamplight Farms Inc., W140 N4900 Lilly Rd., Menomonee Falls, WI 53051

TIKI®, TIKI TORCH®, PARADISE IN YOUR BACKYARD® & The Original Since 1957™ are trademarks of Lamplight Farms Inc. TIKI®, TIKI TORCH®, PARADISE IN YOUR BACKYARD® y The Original Since 1957™ son marcas de Lamplight Farms Inc.

Customer Service/Servicio al cliente:

1-888-473-1088

Made in China/Hecho en China

www.tikibrand.com

PELIGRO: EL COMBUSTIBLE DE LA ANTORCHA ES DAÑINO O MORTAL SI SE INGIERE. CONTIENE HIDROCARBUROS DE PETRÓLEO. LEA CUIDADOSAMENTE LAS ADVERTENCIAS EN EL ENVASE DEL COMBUSTIBLE DE LA ANTORCHA.

ADVERTENCIA: PARA USO EN EXTERIORES SOLAMENTE. MANTENGA ALEJADO DEL ALCANCE DE LOS NIÑOS Y LAS MASCOTAS. NUNCA DEJE UNA ANTORCHA ENCENDIDA SIN SUPERVISIÓN. SI NO RESPETA LAS ADVERTENCIAS E INSTRUCCIONES PUEDE PRODUCIR LESIONES PERSONALES O DAÑOS MATERIALES GRAVES.

ADVERTENCIA: USE ÚNICAMENTE COMBUSTIBLE PARA ANTORCHAS DE MARCA TIKI®, NO UTILICE GASOLINA NI NINGÚN OTRO COMBUSTIBLE INFLAMABLE.

PRECAUCIÓN: Utilice sólo en áreas bien ventiladas. No lo utilice cuando haya mucho viento. Use sólo con mechas de marca TIKI®. Guarde el combustible en el recipiente de combustible original y la tapa bien puesta; deseche el combustible que no necesite según las leyes y normas locales.

INSTRUCCIONES DE USO:

- 1. Instalación:** Introduzca la varilla de la antorcha en el suelo al menos 15,24 cm, hasta que esté firme. No coloque la antorcha debajo de un refugio cubierto ni de sombrillas, ni tampoco cerca de la circulación peatonal ni de elementos combustibles tales como estructuras de madera, combustible, ropa o vegetación seca. Antes de encender la antorcha retire la etiqueta colgante y guárdela como referencia.
- 2. Llenado:** Desenrosque el protector para fuego de metal del recipiente y llene con combustible para antorchas de marca TIKI®. EVITE LLENAR EN EXCESO. Vuelva a colocar el protector para fuego de metal en el recipiente. NO APRIETE DEMASIADO. Limpie el combustible derramado antes de encender. Coloque el recipiente en la antorcha.
- 3. Encendido:** Deje que la mecha se moje completamente con combustible. La mecha expuesta no debe superar los 1,9 cm. **PRECAUCIÓN:** Mantenga la ropa, cabello y cara lejos de la flama cuando encienda la antorcha.
- 4. Apagado:** Coloque la tapa apagavelas unida a la antorcha completamente sobre la mecha hasta que se apague la flama. Coloque la tapa apagavelas sobre la mecha para proteger esta última de los elementos climáticos. Deje enfriar durante 30 minutos antes de manipular y rellenar.