



Paradise In Your Backyard®

Torch Replacement Canister Warnings & Instructions

INSTRUCTIONS FOR USE:

1. **INSTALLING:** Insert torch pole into ground minimum of 6" until secured. Do not place torch under covered shelter, near pedestrian traffic or combustibles such as wood structures, fuel, clothing or dry vegetation. Remove hang tag before lighting and retain for reference.
2. **FILLING:** Unscrew metal flame guard from canister and fill with TIKI® Brand Torch Fuel. **DO NOT OVER FILL.** Reattach metal flame guard to canister. **DO NOT OVER TIGHTEN.** Place canister in torch.
3. **LIGHTING:** Allow wick to become saturated with fuel. Exposed wick should be no higher than 1/2".
CAUTION: Keep clothing, hair and face away from flame when lighting.
4. **EXTINGUISHING:** Using the snuffer cap that is attached to the torch, carefully place completely over wick until flame is extinguished. To prevent snuffer cap from igniting, remove after flame is extinguished and allow the wick to cool. Place snuffer cap over wick to protect from elements.

WARNING: FOR OUTDOOR USE ONLY! KEEP OUT OF REACH OF CHILDREN AND PETS-NEVER LEAVE A BURNING TORCH UNATTENDED. FAILURE TO FOLLOW WARNINGS AND INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE.

WARNING: USE ONLY TIKI® BRAND TORCH FUEL-DO NOT USE GASOLINE OR OTHER FLAMMABLE FUELS. USE ONLY TIKI® BRAND WICKS.
WARNING: TORCH FUEL IS HARMFUL OR FATAL IF SWALLOWED. CONTAINS PETROLEUM HYDRO-CARBONS. Only use canisters with TIKI® Brand Torches that have a circular opening at the top of the torch.

CALIFORNIA PROP. 65 WARNING: This product and combustion products emitted when this product is burning may contain chemicals known to the State of California to cause cancer, birth defects or reproductive harm.

READ WARNINGS ON TORCH FUEL CONTAINER CAREFULLY. Use only in well-ventilated area. Do not use in windy conditions. Do not tip torch as fuel can spill and cause fire or serious injury. Do not use canister outside of torch.

2012 Lamplight Farms Inc. • W140 N4900 Lilly Rd., Menomonee Falls, WI 53051 • www.tikibrand.com
www.lamplight.com
Made in China • Hecho en China
TIKI® and TIKI TORCH® are registered trademarks of Lamplight Farms Inc. • TIKI® y TIKI TORCH® son marcas registradas de Lamplight Farms Inc.

INSTRUCCIONES DE USO:

1. **INSTALACIÓN:** Introduzca la varilla de la antorcha en el suelo al menos 15,24 cm, hasta que esté firme. No coloque la antorcha bajo un refugio cubierto, cerca de zonas de tránsito peatonal ni de combustibles como estructuras de madera, gasolina, ropa o vegetación seca. Antes de encender la antorcha retire la etiqueta colgante y guárdela como referencia.
2. **LLENADO:** Desenrosque el protector para fuego de metal del recipiente y llene con combustible para antorchas de marca TIKI®. **EVITE LLENAR EN EXCESO.** Vuelva a colocar el protector para fuego de metal en el recipiente. **NO APRIETE DEMASIADO.** Coloque el recipiente en la antorcha.
3. **ENCENDIDO:** Deje que la mecha se moje completamente con combustible. La mecha expuesta no debe superar los 1,91 cm. **PRECAUCIÓN:** Mantenga la ropa, cabello y cara lejos de la flama cuando encienda la antorcha.
4. **APAGADO:** Coloque la tapa apagavelas unida a la antorcha completamente sobre la mecha hasta que se apague la flama. Para evitar que la tapa apagavelas se encienda, retírela cuando la mecha esté apagada y deje que la mecha enfríe. Coloque la tapa apagavelas sobre la mecha para proteger esta última de los elementos climáticos.

ADVERTENCIA: PARA USO EN EXTERIORES SOLAMENTE. MANTENGA ALEJADO DEL ALCANCE DE LOS NIÑOS Y LAS MASCOTAS. NUNCA DEJE UNA ANTORCHA ENCENDIDA SIN SUPERVISIÓN. SI NO RESPETA LAS ADVERTENCIAS E INSTRUCCIONES PUEDE PRODUCIR LESIONES PERSONALES O DAÑOS MATERIALES GRAVES.

ADVERTENCIA: USE ÚNICAMENTE COMBUSTIBLE PARA ANTORCHAS DE MARCA TIKI®, NO UTILICE GASOLINA NI NINGÚN OTRO COMBUSTIBLE INFLAMABLE. Use sólo con mechas de marca TIKI®.

ADVERTENCIA: EL COMBUSTIBLE DE LA ANTORCHA ES DAÑINO O MORTAL SI SE INGIERE. CONTIENE HIDROCARBUROS DE PETRÓLEO.
Si solo utilice cartuchos con antorchas de marca TIKI® que tiene una abertura circular en la parte superior de la antorcha.

LEA LAS ADVERTENCIAS EN EL ENVASE DEL COMBUSTIBLE DE LA ANTORCHA. Utilice sólo en áreas bien ventiladas. No lo utilice cuando haya mucho viento. No incline la antorcha, ya que el combustible puede derramarse y causar incendios o lesiones serias. No utilice un recipiente fuera de la antorcha.