



Paradise In Your Backyard®

## Table Torch Warnings & Instructions

**⚠DANGER:** TORCH FUEL IS HARMFUL OR FATAL IF SWALLOWED. CONTAINS PETROLEUM HYDROCARBONS. READ WARNINGS ON TORCH FUEL CONTAINER CAREFULLY.

**⚠WARNING:** FOR OUTDOOR TABLETOP USE ONLY! KEEP OUT OF REACH OF CHILDREN AND PETS. NEVER LEAVE A BURNING TORCH UNATTENDED. FAILURE TO FOLLOW WARNINGS AND INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE.

**⚠WARNING:** USE ONLY TIKI® BRAND FUELS - DO NOT USE GASOLINE OR OTHER FLAMMABLE FUELS.

**⚠CAUTION:** Use only in well-ventilated area. Do not use in windy conditions. Use only TIKI® Brand Wicks. Do not tip torch as fuel can spill and cause fire or serious injury. Store fuel in original fuel bottle with cap secured, and dispose of any unwanted fuel in accordance to local laws and regulations.

### INSTRUCTIONS FOR USE:

**1. INSTALLING:** Do not place torch under covered shelter or umbrellas, near pedestrian traffic or combustibles such as wood structures, fuel, clothing or dry vegetation. Retain these instructions for reference.

**2. FILLING:** Unscrew metal cap and wick assembly from the torch and fill with TIKI® Brand Torch Fuel. Fill torch 1/2" from top. DO NOT OVERFILL. Reattach metal cap and wick assembly to torch. DO NOT OVERTIGHTEN. Wipe away any spilled fuel before lighting.

**⚠CAUTION:** Place on temperature safe surface.

**3. LIGHTING:** Allow wick to become saturated with fuel. Exposed wick should be no higher than 1/2".

**⚠CAUTION:** Keep clothing, hair and face away from flame when lighting. 4. EXTINGUISHING: Using the snuffer cap that is attached to the torch, carefully place completely over wick until flame is extinguished. Place snuffer cap over wick to protect from elements. Allow to cool for 30 minutes before handling and refilling.

©2015 Lamplight Farms Inc., W140 N4900 Lilly Rd., Menomonee Falls, WI 53051

TIKI® & Paradise In Your Backyard® are trademarks of Lamplight Farms Inc. TIKI® y Paradise In Your Backyard® son marcas de Lamplight Farms Inc. [www.tikibrand.com](http://www.tikibrand.com)

Made in China / Hecho en China

Customer Service: / Servicio al cliente: 1-888-473-1088

**⚠PELIGRO:** EL COMBUSTIBLE DE LA ANTORCHA ES DAÑINO O MORTAL SI SE INGIERE. CONTIENE HIDROCARBUROS DE PETRÓLEO. LEA CUIDADOSAMENTE LAS ADVERTENCIAS EN EL ENVASE DEL COMBUSTIBLE DE LA ANTORCHA.

**⚠ADVERTENCIA:** SÓLO PARA USO SOBRE CUBIERTAS DE MESA EN EXTERIORES. MANTENGA ALEJADO DEL ALCANCE DE LOS NIÑOS Y LAS MASCOTAS. NUNCA DEJE UNA ANTORCHA ENCENDIDA SIN SUPERVISIÓN. SI NO RESPETA LAS ADVERTENCIAS E INSTRUCCIONES PUEDE PRODUCIR LESIONES PERSONALES O DAÑOS MATERIALES GRAVES.

**⚠ADVERTENCIA:** USE ÚNICAMENTE COMBUSTIBLE DE MARCA TIKI®, NO UTILICE GASOLINA NI NINGÚN OTRO COMBUSTIBLE INFLAMABLE.

**⚠PRECAUCIÓN:** Utilice sólo en áreas bien ventiladas. No lo utilice cuando haya mucho viento. Use sólo con mechas de marca TIKI®. Guarde el combustible en el recipiente de combustible original y la tapa bien puesta; deseche el combustible que no necesite según las leyes y normas locales.

### INSTRUCCIONES DE USO:

**1. Instalación:** No coloque la antorcha debajo de un refugio cubierto ni de sombrillas, ni tampoco cerca de la circulación peatonal ni de elementos combustibles tales como estructuras de madera, combustible, ropa o vegetación seca. Antes de encender la antorcha retire la etiqueta colgante y guárdela como referencia.

**2. Llenado:** Desenrosque la tapa de metal y el ensamble de la mecha de la antorcha y llene con combustible para antorchas de marca TIKI®. Llene la antorcha con 1,27 cm de la parte superior. EVITE LLENAR EN EXCESO. Vuelva a colocar la tapa de metal y el ensamble de la mecha sobre la antorcha. NO APRIETE DEMASIADO. Limpie el combustible derramado antes de encender.

**⚠PRECAUCIÓN:** Coloque sobre una superficie segura para las temperaturas altas.

**3. Encendido:** Deje que la mecha se moje completamente con combustible. La mecha expuesta no debe superar los 1,27 cm. **⚠PRECAUCIÓN:** Mantenga la ropa, cabello y cara lejos de la flama cuando encienda la antorcha.

**4. Apagado:** Coloque la tapa apagavelas unida a la antorcha completamente sobre la mecha hasta que se apague la flama. Coloque la tapa apagavelas sobre la mecha para proteger esta última de los elementos climáticos. Deje enfriar durante 30 minutos antes de manipular y rellenar.