



Paradise In Your Backyard®

## Island King Torch Warnings & Instructions

**DANGER:** TORCH FUEL IS HARMFUL OR FATAL IF SWALLOWED. CONTAINS PETROLEUM HYDROCARBONS. READ WARNINGS ON TORCH FUEL CONTAINER CAREFULLY.

**WARNING:** FOR OUTDOOR USE ONLY! KEEP OUT OF REACH OF CHILDREN AND PETS. NEVER LEAVE A BURNING TORCH UNATTENDED. FAILURE TO FOLLOW WARNINGS AND INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE.

**WARNING:** IF THIS TORCH TIPS OVER, FUEL CAN SPILL OUT, CAUSING FIRE AND INJURY. BE SURE POLE IS SECURE.

m**WARNING:** USE ONLY TIKI® BRAND TORCH FUEL - DO NOT USE GASOLINE OR OTHER FLAMMABLE FUELS.

**CALIFORNIA PROP. 65 WARNING:** This product and combustion products emitted when this product is burning may contain chemicals known to the State of California to cause cancer, birth defects or reproductive harm.

**CAUTION:** Use only in well-ventilated area. Do not use in high wind conditions. Torch may tip or fall. Use only TIKI® Brand Wicks. TIKI® ISLAND KING® Large Flame Torch is recommended for use with the TIKI® Brand Torch Stand (sold separately). Store fuel in original fuel bottle with cap secured, and dispose of any unwanted fuel in accordance to local laws and regulations. Remove hang tag before lighting and retain for reference.

©2015 Lamplight Farms Inc., W140 N4900 Lilly Rd., Menomonee Falls, WI 53051

TIKI®, Paradise In Your Backyard®, TIKI TORCH®, Island King®, BiteFighter® & TWIST & POUR are trademarks of Lamplight Farms Inc. • TIKI®, Paradise In Your Backyard®, TIKI TORCH®, Island King®, BiteFighter® y TWIST & POUR™ son marcas de Lamplight Farms Inc.

Designed and Engineered in Menomonee Falls, WI. Assembled in China. Diseñado y creado en Menomonee Falls, Wisconsin. Ensamblado en China. [www.tikibrand.com](http://www.tikibrand.com)

Customer Service/Servicio al cliente: 1-888-473-1088  
Patent Pending/Patente en trámite

**PELIGRO:** EL COMBUSTIBLE DE LA ANTORCHA ES DAÑINO O MORTAL SI SE INGIERE. CONTIENE HIDROCARBUROS DE PETRÓLEO. LEA CUIDADOSAMENTE LAS ADVERTENCIAS EN EL ENVASE DEL COMBUSTIBLE DE LA ANTORCHA.

**ADVERTENCIA:** PARA USO EN EXTERIORES SOLAMENTE. MANTENGA ALEJADO DEL ALCANCE DE LOS NIÑOS Y LAS MASCOTAS. NUNCA DEJE UNA ANTORCHA ENCENDIDA SIN SUPERVISIÓN. SI NO RESPETA LAS ADVERTENCIAS E INSTRUCCIONES PUEDE PRODUCIR LESIONES PERSONALES O DAÑOS MATERIALES GRAVES.

**ADVERTENCIA:** SI ESTA ANTORCHA SE VUELCA, EL COMBUSTIBLE PUEDE DERRAMARSE, LO QUE CAUSARÍA UN INCENDIO Y LESIONES. ASEGÚRESE DE QUE EL POSTE ESTÉ FIRME.

m**ADVERTENCIA:** USE ÚNICAMENTE COMBUSTIBLE PARA ANTORCHAS DE MARCA TIKI®, NO UTILICE GASOLINA NI NINGÚN OTRO COMBUSTIBLE INFLAMABLE.

**PRECAUCIÓN:** Utilice sólo en áreas bien ventiladas. No lo use cuando haya viento fuerte. La antorcha puede inclinarse o caer. Use sólo con mechas de marca TIKI®. Se recomienda la antorcha con llama grande TIKI® ISLAND KING® para su uso con la base para antorcha de marca TIKI® (se vende por separado). Guarde el combustible en el recipiente de combustible original y la tapa bien puesta; deseche el combustible que no necesite según las leyes y normas locales. Antes de encender la antorcha retire la etiqueta colgante y guárdela como referencia.