



Paradise In Your Backyard®

## Torch Stake Warnings & Instructions

### **TORCH STAKE**

The torch stake makes it easy to secure your favorite TIKI® Brand torch in the ground. Fits torch poles up to 1 1/4" diameter.

### **INSTRUCTIONS FOR USE:**

1. Choose desired torch location.
2. Insert the "Torch Stake" into the ground using a rubber mallet. Insert stake into ground as shown. Keep stake upright to prevent torch from leaning.
3. Place torch through stake and into ground 2". Tighten bolt to secure.

### **FOR OUTDOOR USE ONLY.**

### **WARNING:**

Do not use with torch poles smaller than 3/4" diameter.

**CALIFORNIA PROP. 65 WARNING:** This product may contain chemicals known to the State of California to cause cancer, birth defects or reproductive harm.

©2015 Lamplight Farms Inc. W140 N4900 Lilly Rd., Menomonee Falls, WI 53051

TIKI® & Paradise In Your Backyard® are trademarks of Lamplight Farms Inc. / TIKI® y Paradise In Your Backyard® son marcas de Lamplight Farms Inc.

[www.tikibrand.com](http://www.tikibrand.com)

Made in China/Hecho en China

Customer Service/Servicio al cliente: 1-888-473-1088

### **ESTACA PARA ANTORCHA**

La estaca para antorcha facilita la fijación de sus antorchas favoritas marca TIKI® al suelo.

Se ajusta a postes de antorcha de hasta 3,18 cm de diámetro.

### **INSTRUCCIONES DE USO:**

1. Elija la ubicación deseada de la antorcha.
2. Inserte la "estaca para antorcha" en el suelo con un mazo de goma. Inserte la estaca en el suelo tal como se muestra. Mantenga la estaca en posición vertical para evitar que se incline.
3. Coloque la antorcha a través de la estaca y en el suelo a una profundidad de 5,08 cm. Apriete el perno para asegurar.

### **SÓLO PARA USO EN EXTERIORES.**

### **ADVERTENCIA:**

No use con postes de antorcha que tengan menos de 1,91 cm de diámetro.